

QUICK SUMMARY OF HP PRINTER HISTORY AND REPLACEMENT PRODUCTS

LaserJet's

LaserJet 1000w → LaserJet 1010 → **LaserJet 1020**
LaserJet 1005w → LaserJet 1012 → **LaserJet 1022**
LaserJet 1018
LaserJet 1015 → **LaserJet 1022**

LaserJet 1150 → **LaserJet 1160**

LaserJet 4L → LaserJet 5L → LaserJet 6L → LaserJet 1100 → LaserJet 1200 → LaserJet 1300 →
LaserJet 1320 → Laserjet 2015 range
LaserJet 1200n → LaserJet 1300n → **LaserJet 1320n → Laserjet 2015 range**

LaserJet IIP → LaserJet IIIP → LaserJet 4P → LaserJet 5P → LaserJet 6P → LaserJet 2100 →
LaserJet 2200 → LaserJet 2300L → Laserjet 2410 → **OBSOLETE**
LaserJet 2300 range → **Laserjet 2420 range → Laserjet P3005 range**

Laserjet 2430 → Laserjet P3005 range

LaserJet III → LaserJet 4 → LaserJet 4 Plus → LaserJet 5 → LaserJet 4000 → LaserJet 4050 →
LaserJet 4100 → LaserJet 4200 → **LaserJet 4250 range**

LaserJet 4300 → **LaserJet 4350 range**

LaserJet 4V → LaserJet 5000 → LaserJet 5100 → **LaserJet 5200**

LaserJet 9040

LaserJet IIISi → LaserJet 4Si → LaserJet 5Si → LaserJet 8000 → LaserJet 8100 →
LaserJet 8150 → LaserJet 9000 → **LaserJet 9050**

LaserJet 1220 → LaserJet 3300/3320mfp → LaserJet 3015 → **LaserJet 3050**

LaserJet 3020mfp → LaserJet 3052

LaserJet 3030mfp → LaserJet 3055

LaserJet 3380mfp → LaserJet 3390

Laserjet 3392

Laserjet M1005mfp

LaserJet 4100mfp → **LaserJet 4345mfp range**

Laserjet M4345mfp range

LaserJet 9000L mfp → **LaserJet 9040mfp**

LaserJet 9000 mfp → **LaserJet 9050mfp**

Colour LaserJet's

Colour LaserJet 1500 range → **Colour LaserJet 1600**

Colour LaserJet 2500 range → Colour Laserjet 2550 range → **Colour Laserjet 2605 range**

Colour LaserJet 2600N

Colout Laserjet CLJ 2700 range

Colour LaserJet 3000 range

Colour LaserJet 3500 → **Colour LaserJet 3600 range**

Colour LaserJet 3550 → *OBSOLETE*

Colour LaserJet 3700 → **Colour LaserJet 3800 range**

Colout Laserjet CP4005 range

Colour LaserJet → Colour LaserJet 5 → Colour LaserJet 6 → Colour LaserJet 4500 → Colour LaserJet 4550 → Colour LaserJet 4600 → Colour LaserJet 4650 → **Colour LaserJet 4700 range**

Colour LaserJet 8500 → Colour LaserJet 8550 → Colour LaserJet 5500 → **Colour LaserJet 5550**

Colour LaserJet 9500

Colour Laserjet M1015mfp

Colour Laserjet M1017mfp

Colour Laserjet J2820mfp

Colour Laserjet J2840mfp

Colour Laserjet J4730mfp Range

Colour LaserJet 8550mfp → **Colour LaserJet 9500mfp**

DIGITAL SENDER

Digital Sender 9200c

DeskJet's

HP Portable → DeskJet 310 → DeskJet 320 → DeskJet 340 → DeskJet 350c → DeskJet 450ci → **DeskJet 460c**

DeskJet 350cbi → DeskJet 450cbi → **DeskJet 460cb**

DeskJet 450wbt → **DeskJet 460wbt**

Deskjet D1360

DeskJet 656c → DeskJet 3325 → DeskJet 3550 → DJ3745 → DJ3940 → **D2360**

DeskJet → DeskJet + → DeskJet 500 → DeskJet 510 → DeskJet 520 → DeskJet 540 → DeskJet 600 → DeskJet 400 → DeskJet 420 → DeskJet 610 → DeskJet 640 → DeskJet 845 → DeskJet 3420 → DeskJet 3550 → DJ3745 → DJ3940 → **D2360**

DeskJet 840c → DeskJet 920c → DeskJet 3820 → DeskJet 3650 → DeskJet 3845 → DeskJet 5443 → **DeskJet 4163**

DeskJet 710c → DeskJet 820cxi → DeskJet 720c → DeskJet 815c → DeskJet 930 → DeskJet 940 → DeskJet 5550 → DeskJet 5150 → DeskJet 5743 → DeskJet 5943 → **Photosmart D5063**

DeskJet 500c → DeskJet 550c → DeskJet 560c → DeskJet 660c → DeskJet 690/5 → DeskJet 880c → DeskJet 959cxi → DeskJet 960 → DeskJet 6122 → DeskJet 5652 → DeskJet 6543 → DeskJet 5943 → **Photosmart D5063**

DeskJet 6623 → **DeskJet 6943**

DeskJet 850c → DeskJet 870cxi → DeskJet 890c → DeskJet 895cxi →
DeskJet 970cxi → DeskJet 980c → DeskJet 990cxi → DeskJet 6127 → DeskJet 5850 → DeskJet 6843 →
DeskJet 6983

DeskJet CP1160 → **OBSOLETE**

Business Inkjet 1000

Business Inkjet 1100d range → Business Inkjet 1200d range → BIJ Officejet Pro K550 range → **Officejet Pro K5400**

HP2000C → Business InkJet 2200 → Business InkJet 2230 → **Business InkJet 2300**

Business InkJet 2250 → Business InkJet 2280 → **Business InkJet 2300**

Business InkJet 2300N

Business InkJet 2250TN → Business InkJet 2280TN → **Business InkJet 2300DTN**

Business InkJet 3000 → **OBSOLETE**

DeskJet 1100c → DeskJet 1120c → DeskJet 1125c → DeskJet 1220c → **DeskJet 1280**

DeskJet 9300 → **DeskJet 9803**

Deskjet 9650 → **DeskJet 9803**

Deskjet 9670 → **DeskJet 9803d**

Deskjet 9680 → **DeskJet 9803d**

BIJ Officejet Pro K850 range

DeskJet CP1700/D/PS → **BIJ2800**

DeskJet 1200c → DeskJet 1600c → HP2500c → HP2600 range → **BIJ2800 range**

OfficeJet's

OfficeJet Pro 1150 → OfficeJet 1170/5 → OfficeJet R45/65 → OfficeJet G55 → OfficeJet D125xi →
OBSOLETE

OfficeJet G85 → OfficeJet 6110 → OfficeJet 6213 → **OfficeJet 6313**

OfficeJet D135 → OfficeJet 7110 → OfficeJet 7213 → **Officejet Pro L7580**

OfficeJet D145 → OfficeJet 7130 → OfficeJet 7313 → **Officejet Pro L7680**

OfficeJet G95 → OfficeJet D155xi → OfficeJet 7140xi → OfficeJet 7413 → **OBSOLETE**

OfficeJet 4110 → OfficeJet 4255 → **OfficeJet 4355**

OfficeJet 635c → OfficeJet 710c → OfficeJet V40 → OfficeJet 5110 → **OBSOLETE**

OfficeJet T65 → OfficeJet K80 → **OBSOLETE**

OfficeJet PSC 750 → OfficeJet PSC2110 → OfficeJet PSC2510 → OfficeJet PSC2713 →
OfficeJet PSC3313 → **OfficeJet C7183**

OfficeJet PSC 950 → OfficeJet PSC2210 → OfficeJet PSC2410 → OfficeJet PSC2613 →
OfficeJet PSC3312 → **OBSOLETE**

OfficeJet 5510 → **Officejet 5610**

Officejet PSC 1110 → Officejet PSC 1215 → Officejet PSC 1410 → **F380**

Officejet PSC 1210 → Officejet PSC 1315 → Officejet PSC 1513 → **Photosmart C3183**

Officejet PSC 1350 → Officejet PSC 1613 → **Photosmart C4183**

Officejet 2175 → Officejet 2353 → **Officejet 2573**

Officejet 3213 → **Officejet 6183**

Officejet 9110

Officejet 9120

Officejet 9130

ScanJet's

ScanJet 2200 → ScanJet 2300 → **ScanJet 2400**

ScanJet 3200 → ScanJet 3300 → ScanJet 3400 → ScanJet 3500 → ScanJet 3670 → ScanJet 3770 → **ScanJet 3800**

ScanJet 4200 → ScanJet 4300 → ScanJet 4400 → ScanJet 3530 → ScanJet 3690 → **OBSOLETE**

ScanJet 4470 → ScanJet 3570 → ScanJet 3970 → ScanJet 4370 → **ScanJet G3010**

Scanjet 4070 → **ScanJet 4850**

Scanjet N6010

ScanJet 4890

ScanJet 5200 → ScanJet 5300 → ScanJet 5400 → ScanJet 4500 → ScanJet 4600 → **ScanJet 4600P** → **OBSOLETE**

ScanJet 5470 → ScanJet 4570 → ScanJet 4670 → ScanJet 4670VP → **OBSOLETE**

ScanJet 5490 → ScanJet 5500 → ScanJet 5550 → **ScanJet 5590**

Scanjet 5500c → ScanJet 5530 → **OBSOLETE**

ScanJet 6200 → ScanJet 6300 → ScanJet 7400 → **OBSOLETE**
ScanJet 7450 → **ScanJet 7650**
ScanJet 7650n
ScanJet 7490 → **OBSOLETE**

ScanJet 7800

ScanJet 8270

ScanJet 8200 → **Scanjet 8300**

Scanjet 8300gp

ScanJet 8250 → **ScanJet 8350**

ScanJet 8290 → **Scanjet 8390**

Photography

Cameras

P120 → **OBSOLETE**

E327 → E427

C315 → C318 → P320 → P435 → M307 → M22/M23 → **OBSOLETE**

M425 → Obsolete

C612 → P620 → P635 → M407 → M417 → M525 → **OBOLETE**

C715 → P720 → P735 → M507 → M517 → M527 → **OBOLETE**

M627

C812 → P935 → R707 → R717 → R727 → **OBOLETE**

R817 → **R927**

R818

R827 → OBOLETE

C850 → P945 → **OBSOLETE**

R967

Printers

Photosmart 1115 → P7150 → P7260 → P7450 → **DeskJet 5943 → D5063**

Photosmart 1215 → P7350 → P7660 → P8153 → **P8053 → D7163**

Photosmart 1315 → P7550 → P7760 → P8453 → P8253 → **D7363**

Photosmart C5183

Photosmart P7960 → **P8753**

Photosmart P100 → P130 → P145 → **P325 → P335 → OBOLETE**

Photosmart P230 → P245 → **P375 → P385 → OBOLETE**

PS475

Photosmart A516

Photosmart A618

Photosmart A717